


### 4040 Series Arms, Plates & Shoes

#### LC4040 16 AL

- Corner bracket for doors where top jamb or parallel arm mounting cannot be used.

**EZ # 035866**




#### LC4040 18TJ ALUM

- Centers top jamb mounted closer vertically.
- Requires 1-3/4" minimum head frame.

**EZ# 026791 (ALUM)**

**EZ# 072970 (DURO)**




#### LC4040 18G

- Locates top jamb mounted closer flush with top of head frame face.
- Requires 1-3/4" minimum head frame.

**EZ# 008560 (ALUM)**

**EZ# 035868 (DURO)**




#### LC4040 18PA

- Required for parallel arm mounting where top rail is less than 5-1/2" measured from stop.
- Plate requires 2" minimum top rail.

**EZ# 008561 (ALUM)**


**EZ # 035867 (DURO)**



#### LC4040 18ALUM

- Required for hinge side mount where top rail is less than 3-3/4" (95mm).
- Requires 2" minimum top rail.


**EZ# 008559**



#### LC4040 3077AL

- Regular arm for 4040.

**EZ# 008563**




### 4040 Arms & Rod & Shoe

#### LC4040 3049AL

- Hold-open arm for 4040.

**EZ# 008566**



#### LC4040 79

- Standard Rod & Shoe

**EZ# 074875**



#### LC4040 79LR

- Extra Long Rod & Shoe

**EZ# 074876**




### 4010 Arm

#### LC4010 3077

- Standard non-handed regular arm

**EZ # 035860**




### 4110 Plate

#### LC4110 18 AL

- Required for push side mount where top rail is less than 5 1/8" measured from the stop. Plate requires minimum 2" minimum top rail. Plate also used with Cush Arm installations.

**EZ # 035869**



### 1460 Arm

#### LC1460 3077 689

- Regular arm

**EZ# 029316**

